





Connections in steel tower




Simple connection - flexible



- Columns:
- IPE 140 x 73
 - IPE 220 x 110
 - IPE 180 x 51
 - IPE 240 x 120
 - IPE 210 x 135
 - IPE 160 x 82

- Beams:
- UHP 220 x 80
 - IPE 240 x 120
 - UHP 240 x 85
 - IPE 270 x 135
 - IPE 100 x 55



- steps
1. Level the beam
 2. Put in mortar
 3. Not to dry later
 4. Remove template level